



## **CENTURY PLUS SERIES INSTALLATION**

Use PTFE® tape (2 wraps) on all connections, hand tight plus 1 1/2 to 2 turns is sufficient.

Valve to be installed with the flow in the direction indicated by the arrows.

For manual operation, loosen the bleed screw. Two or three turns will turn on the valve and retightening the bleed screw will close the valve.

If you remove the metering rod, be sure the rod goes down the center of the hole in the stem when replacing.

Allow enough slack in the solenoid wires to enable the removal of same by maintenance people.

Wire size must be adequate to meet demand of long wiring run or use of multiple solenoids per station.

Piping layout must conform to accepted industry standards. Water velocities in excess of 7 FPS or normal operating pressures in excess of 200 PSI will void your Irritrol Systems guarantee.

Care should be taken to ensure that system is kept free of debris and contaminants to assure positive valve operation.

Improper disassembly and reassembly will void your Irritrol guarantee.

### **Product Inquiries**

P.O. Box 489  
Riverside, CA 92502  
1-800-634-8873

1049501 Rev. B

©1997 Irritrol